



















# Using the Operation Panel

## Operation Panel Keys

	Displays the Home screen.			Puts the machine into Sleep Mode. Recovers from Sleep if in Sleep Mode.	
	Displays the System Menu screen.		Displays the Counter screen.		Puts the machine into Low Power Mode.
	Displays the Status/Job Cancel screen.		Displays the Copy screen.		Authenticates user switching, and exits the operation for the current user (i.e. log out).
	Displays the help guidance.		Displays the screen for sending. You can change it to display the Address Book screen.		Displays the Interrupt Copy screen.
	Switches the touch panel display on the Copy screen and the Send screen to a magnified view.		Displays the FAX screen.		Lit when the machine's main power is on.
	Select the color mode.				
	Auto Color: Automatically recognizes whether a document is color or black & white and then scans the document.				
	Full Color: Scans all documents in full color.				
	Black & White: Scans all documents in black & white.				

Touch panel. Displays buttons for configuring machine settings.










Lights when there is paper in the job separator tray.

Blinks while printing or sending/receiving.

Blinks while the machine is accessing the hard disk, fax memory or USB memory (general purpose item).

Lights or blinks when an error occurs and a job is stopped.

	Numeric keys. Enter numbers and symbols.		Clears entered numbers and characters.		Returns settings to their default states.
			Specifies registered information such as address numbers, user IDs and program numbers by number.		Cancels or pauses the job in progress.
			Finalizes numeric key entry, and finalizes details during setting of functions. Operates linked with the on-screen [OK].		Starts copying and scanning operations and processing for setting operations.